


GraLab Model 300 Photographic Timer Operating Instructions



- General photographic timing
- Two switchable outlets
 - Safelight outlet
 - Enlarger or Printer outlet
- Split second accuracy
- Second hand rotates one revolution/min
- Minute hand rotates one revolution/hour
- Power switch starts the timing cycle
- End of cycle buzzer
 - Adjustable from 0db to 80db
- Luminous Dial
 - Glows 20-30 minutes
 - “Recharge” with incandescent or fluorescent light

Example for Automatic Enlarger Timing

1. Set ON-OFF switch to OFF.
2. Plug enlarger into outlet marked ENLARGER.
3. Set TIME-FOCUS switch to FOCUS.
4. Turn ON-OFF switch to ON and focus enlarger. Then turn to OFF again.
5. Set timer hands clockwise to desired setting. Also, set TIME-FOCUS switch to TIME.
6. Turn ON-OFF switch to ON.

Result: timer will automatically turn enlarger off after selected time interval.

Safelight Operation

1. Plug safelight into outlet marked SAFELIGHT.
2. When TIME-FOCUS switch is set to FOCUS and enlarger is turned on, safelight will be turned off automatically, eliminating any extraneous light.
3. With TIME-FOCUS switch set to TIME and the enlarger if on, safelight is automatically turned off, eliminating shadows when a dodging operation is necessary.
4. When timer hands reach zero automatically turning enlarger off, safelight will automatically turn on providing light for your next operation.
5. You may switch another appliance on after a timed interval by connecting it to the safelight outlet.

PRECAUTIONS

- *To prevent fire or electrical shock, do not expose timer to rain or moisture.*
- *No user serviceable parts inside -- do not open.*
- *Refer servicing to qualified personnel.*
- *Observe AC line voltage, frequency and load ratings on nameplate.*